

## Kitchen connection box



# Hobs and ovens using one connection


### **The kitchen connection box is the universal assembly aid for the kitchen.**

It is used when a hob and an oven are not installed as a combined appliance. The kitchen connection box serves as a power distributor for separately installed kitchen appliances in order to centrally supply them with power from an existing cooker connection socket. It is available

in three different supply cable versions and thereby permits flexible use depending on the situation in the respective kitchen.


It is not necessary to install additional socket outlets, which reduces both the costs and the time required to install the kitchen appliances.

**BACH  
MANN**




# Kitchen connection box

## BENEFITS

- Saves costs as no need to fit additional sockets
- The existing cooker socket can still be used
- Rewirable WAGO® terminals
- Low mounting depth (approx. 34 mm)
- Can also be used in combination with an induction cooker
- Distributor box VDE-approved 

## Kitchen connection box

- Grey, with screw holes, connected load up to 11 kW (with ohmic load)
- H05VV-F 5G 2.50 mm<sup>2</sup> for cooker socket
- H05VV-F 4G 2.50 mm<sup>2</sup> for hob
- H05VV-F 3G 1.50 mm<sup>2</sup> with socket outlet with earthing contact for oven

#	
923.000	<b>Kitchen connection box 2m</b> Cooker connection socket 2.0m   Hob 2.0m and oven 2.0m
923.001	<b>Kitchen connection box 5m</b> Cooker connection socket 2.0m   Hob 5.0m and oven 5.0m
923.002	<b>Kitchen connection box 10m</b> Cooker connection socket 2.0m   Hob 10.0m and oven 10.0m

